

Do not cover luminaire or driver with thermally insulating material (A). It is recommended to allow a minimum of 50 mm clearance from combustible materials, as shown in (B), (C) and (D).




⁶ Restore power once installation has been completed.

5



Maxiled XDL35 Recessed Downlight Installation Guide



Downlights



Maxiled XDL35

trendlighting.com.au



Product designs and technical data may be subject to change.

V1-11.03.2024

For warranty information, please visit


trendlighting.com.au/warranty

Important Safety Information

Please read these installation instructions carefully before installing this luminaire.

- This product must be installed by a licensed electrician in accordance with AS/NZS 3000 and local regulations.
- Isolate the mains power supply prior to installation.
- Only reconnect mains power after installation is completed.
- No part of the luminaire should be altered or modified.
- This product is not user serviceable.


2 Mark at the correct location. Cut a hole in the ceiling in accordance with cutout size. XDL35 ceiling cutout: **150 mm**




Approvals

The RCM marking of this product applies to AS/NZS 4417.1 "Regulatory compliance mark (RCM) for electrical and electronic equipment". This product is designed to conform to AS/NZS 60598 "Luminaires, general requirements and tests".







Lift the springs upward to ensure the luminaire can be installed into the mounting hole.

