



V1-29.02.2024 Product designs and technical data may be subject to change

Mono ZSB20 Tricolour Diffused Batten *Installation Guide*



Scan to explore
ZSB20 online


For warranty information, please visit
trendlighting.com.au/warranty

Important Safety Information

Please read these installation instructions carefully before installing this luminaire.

- This product must be installed by a licensed electrician in accordance with AS/NZS 3000 and local regulations.
- Isolate the mains power supply prior to installation.
- Only adjust the Wattage and CCT switch when luminaire is powered off.
- Only reconnect mains power after installation is completed.
- No part of the luminaire should be altered or modified.
- This product is not user serviceable.

Installation Notes



Ingress Protection Impact Protection

Product Code

ZSB20-TRI-W-ND

Dimensions

600 (L) x 124 (W) x 60 (H) mm

1 Isolate the mains power supply prior to commencing installation.

2 Push the tabs underneath each side of the batten as shown below.

3 Pull both ends of the batten out and then remove the diffuser.

4 Only adjust CCT switch when luminaire is powered off. CCT switch **(A)** is shown below.

5a For **Surface Mounted** installation, attach Luminaire to the ceiling using the designated mounting points.

5b For **Suspended** installation, thread suspension wire through the bracket hole **(B)**. Depress the top of the suspension bracket to lengthen the wire **(C)**.

6 Remove the secure bracket before start wiring

7 Emergency wiring for **Surface Mounted & Suspended** installation is shown below.

Emergency

L' L N

L'= Active (cons.)
L= Switched Active
⊕=Earth
N=Neutral