

7a Switched Maintained: Allows the luminaire to be switched on and off in non-emergency situations. If Active (L') loses power, the luminaire will switch to emergency mode and is energised by the battery backup module.


7b Maintained: The luminaire is always on and is unable to be switched off. If Active (L') loses power, the luminaire will switch from mains operation to emergency mode and is energised by the battery backup module.

8a For **Suspended** installation, put back the diffuser after finished wiring.


8b For **Surface Mounted** installation, put back the diffuser after finished wiring.

Mono ZSB38 Emergency Tricolour Diffused Batten

Installation Guide



V1-29.02.2024 Product designs and technical data may be subject to change



Scan to explore ZSB38 online

For warranty information, please visit
trendlighting.com.au/warranty

Important Safety Information

Please read these installation instructions carefully before installing this luminaire.

- This product must be installed by a licensed electrician in accordance with AS/NZS 3000 and local regulations.
- Isolate the mains power supply prior to installation.
- Only adjust the Wattage and CCT switch when luminaire is powered off.
- Only reconnect mains power after installation is completed.
- No part of the luminaire should be altered or modified.
- This product is not user serviceable.

Installation Notes



Product Codes

ZSB38-TRI-W-ND-EMB

Dimensions

1200 (L) x 124 (W) x 60 (H) mm

